

Thermally Induced Dimensional Variation in Extrusion

Extrusion 2015 November 2-3, 2015
Omni Charlotte Hotel
Charlotte, NC USA

“Thermally Induced Dimensional Variation in Extrusion”
Dr. Chris Rauwendaal
President Rauwendaal Extrusion Engineering, Inc.
Speaker Phone: +1-530-269-1082
Speaker email: chris@rauwendaal.com

Coauthors:
Gregor Hiesgen
Kenny Saul
With SHS plus

PRESENTED BY: **PT** Plastics Technology **GARDNER** Business Media, Inc.

1

Outline

- T-melt variation in extrusion
- Consequences of T-melt variations
- Simulation of the cooling process
- Thermally induced wall thickness variation in pipe extrusion
- Reduce melt temperature variation


2

Melt Temps in Extrusion

- Result of viscous dissipation and heat transfer
- Conductive heat transfer is slow – polymer thermal conductivity low
- Melt temperatures are inherently non-uniform

3


63-mm Extruder at 100 rpm 0.2 MI HDPE (FEA)



Note high melt temperatures in center region – natural **HOT SPOT!**
Next slide expanded vertical scale

4

63-mm Extruder at 100 rpm 0.2 MI HDPE (FEA)



294°C!!

5


Experiments Univ. Bradford E. Brown and A. Kelly

- Melt temperature variation measured at end of 2.5” (63.5-mm) extruder
- Fast response T/C mesh was used
- Three different screws tested
 - Rapid compression
 - Tapered (gradual) compression
 - Barrier type screw

6


Thermally Induced Dimensional Variation in Extrusion

Experimental Setup




7

Screw Geometries




8

Compression Screw 70 rpm




9

Barrier screw 70 rpm



10


Compression vs. Barrier



11


Temperature vs time

compression screw




12


Thermally Induced Dimensional Variation in Extrusion




13




14




15



16



17



18

Thermally Induced Dimensional Variation in Extrusion


Melt temperature variation

- Short term melt temperature variation occurs in **all** extruders
- Can be measured with IR probes - not with immersion probes!
- Can create a variety of problems, e.g. ID waviness in extruded pipe
- Thermal mixing is **CRITICAL!**

19

Pipe ID Waviness

- Common problem
- Caused by melt temperature variation
- Example is shown on the right



20

Causes of wall thickness variation in pipe-1 Overeijnder

- Variations in elastic stresses by folding of the melt in channels of TSE
- Incorrect die design
- Incorrect screw and barrel temperatures
- In coextrusion viscosity differences between layers

21

Causes of wall thickness variation in pipe-2 Overeijnder

- Unmelt at discharge end of the extruder
- Friction at calibration sleeve greater than melt strength
- Improper alignment head and calibrator
- Slipping of puller cleats
- Foamed pipe cell sizes too large (> 0.15 mm)

22

Wall Thickness Variation

- Amplitude typically varies from 0.1 to 3% of the wall thickness
- Frequency varies with cause
- In thermally induced thickness variation, frequency corresponds to melt temperature variation

23

chillWARE® by SMS plus

- Simulates cooling by FEA/FDM
- Material data base
- 2D/3D temperature field
- Residual stress analysis
- Optimization of cooling process
- Optimization US wall thickness

24

Thermally Induced Dimensional Variation in Extrusion


chillWARE® Modules

- Pipe (2D)
- Cable (2D)
- Coex pipe (2D)
- Rod (2D)
- Sheet (3D)
- Profile (3D)

© REE

25

chillWARE® Results



© REE


26

Can answer questions like

- How long a cooling line needed?
- How to reduce operational cost?
- How to reduce residual stress, shrinkage, sagging, etc.?
- Temperatures along length of line?
- What is optimum layout?
- How long for crystallization?

© REE

27



© REE

28


Pipe Extrusion

- OD is fixed by calibrator
- Outer surface cools & solidifies first
- Inner layers cool more slowly and shrink toward outer diameter
- With non-uniform melt temps this results in wall thickness variation

© REE

29


Density vs Temperature



30

Thermally Induced Dimensional Variation in Extrusion

Adjustable Calibration



© REE

31

Process Data

Parameter	Unit	Value
Material	-	PE 100
Final Outer Diameter	mm	250
Final Wall Thickness	mm	24
Mass Throughput	kg/h	350
Melt Temperature Case 1	°C	218
Melt Temperature Case 2	°C	188
Processing Velocity	m/min	0.35
Outer Diameter of Calibration	mm	256.6
Wall Thickness @ Extrusion Die	mm	31.04

© REE

32


Cooling Section

- Vacuum calibration length 600 mm
- Two vacuum spray cooling tanks length 9,000 mm each
- Two spray cooling tanks with a length of 9,000 mm each

© REE

33

chillWARE results



© REE

34

reference production process


- 7.6 kW thermal power is dissipated in vacuum calibration unit
- Outer surface temperature 47.4°C, inner temperature still at 218°C
- Average cross sectional temperature is 194°C

© REE

35

Temperatures at T_m 218°C


Temperature distribution at end of calibration




© REE

36


Thermally Induced Dimensional Variation in Extrusion




37




38




39



40



41



42

Thermally Induced Dimensional Variation in Extrusion

Reduce T-melt Variation

- Use IR T-melt measurement!
- Improve thermal mixing by
 - Dynamic distributive mixers
 - Static mixers
 - Axial mixing is most important!
- Large inventory dies ineffective

XXXXXXXXXX
XXXXXXXXXX
XXXXXXXXXX

© REE

43

Thank You!

- Organizers for the opportunity to present this information
- Attendees for your attention
- Any questions?

XXXXXXXXXX
XXXXXXXXXX
XXXXXXXXXX

© REE

44